




beroNet 

Le SIP Trunk Touch OpenIP configuré sur les Passerelles Beronet



Paramètres de configuration du SIP Trunk Touch



SIP CONFIGURATION

Settings More

Name* OpenIP

SIP outbound proxy **Adresse du serveur « voip.myopenip.fr »**

SIP registrar* voip.myopenip.fr

SIP domain

ENUM Support

User **Login du SIP Trunk Touch**

Authentication user

Displayname

Secret **Mot de passe du SIP Trunk Touch**

Match type* IP Address From User To User Contact User Request-URI User Manual

Call Transfer Method refer

SIP transport udp

NAT options No-NAT STUN-Server Extern-IP

Register

Registration interval* 300

Keepalive-Interval* no-validate

Keepalive-Interval 0

* Required fields

Save